13P2 Hook Panel Specifications

PART 1 - GENERAL

- 1. DESCRIPTION: Furnish and install wall mounted hook panels.
- 2. RELATED WORK: (Refer to Section of Specs which applies to wall blocking.)

PART 2 - PRODUCTS

- 1. MANUFACTURER: 13P2 series hook panel by EMCO Specialty Products, Inc., Kansas City, KS.
- 2. MATERIALS: Panel shall be of solid (walnut or oak) 5/8"x 5 5/8"x 17" hardwood and drilled for standard number of hooks. The finish is to be (specify walnut, medium oak, or light oak).
- 3. 13P2 panels shall have two P1 hooks (specify finish either silver or black) and one Y10 slotted hook to accommodate two hangers. All hooks to be installed at the factory.
- 4. ACCESSORIES: One EMCO hanger No.13 ball top hanger shall be provided for each available slot in the center hook. Hanger to match panel finish.

PART 3 - EXECUTION

INSTALLATION:

- 1. Install wall blocking.
- 2. Install concealed fastener mounting plate to wall using "fasteners by others" appropriate for wall type.
- 3. Install panel at height specified by architect.
- 4. Check to make sure it is level.
- 5. Remove adhesive backing strip from back of panel.
- 6. Slide panel concealed fastener over wall mounting plate.
- 7. Install hangers in hook slots.
- 8. Wipe down panel to remove dust.
- 9. Remove all trash and debris.